



Twist rope loop to form an 'X' and secure in place by using the supplied retainer.



Slide the inverted rubber stand-up boot over the loop and slide it up the block as far as possible.

Thread the bow shackle through the rope loop ensuring that the ratchet rotation is correct.



Tighten the shackle with a screwdriver making sure that the shackle is positioned with the pin at the bottom against the saddle.



Roll down the boot and align it over the saddle.



Thread through the mainsheet.



Go Sailing!